




Instructions d'installation
Installationsanweisungen
Instrucciones de instalación
Istruzioni per l'installazione
Installatie-instructies
インストール手順
安裝指示
إرشادات التركيب



De apparaten moeten worden aangebracht door een gekwalificeerde elektricien en in overeenstemming met alle nationale en plaatselijke elektriciteits- en bouwvoorschriften.

يجب تركيب الأجهزة من قبل فني كهربائي مؤهل وفقاً لكافة قوانين ولوائح التركيب الكهربائي المحلي والوطني.











PIR

Diagram illustrating the layout and dimensions of a 3000W LED lighting fixture with PIR sensor and fan. The fixture is shown in a perspective view, highlighting its dimensions and the sensor's field of view.

Key dimensions and features:

- Height:** $h \leq 15 \text{ m}$ (49.2 ft)
- Width:** $0.07 \times h^*$
- Length:** $1.75 \times h^*$ (left section), $2 \times h^*$ (middle section), $1.75 \times h^*$ (right section)
- Angles:** 40° (left and right sections), 0° (middle section)
- Distance:** $> 2 \text{ m}$ (6.5 ft)
- IEC Pollution Degree II**
- Temperature:** $* \leq 25^\circ \text{C}$ (77°F)





⚠ Do not connect inputs to mains.

⚙ Installation of a home and building automation and control system shall comply with HD 60364-4-41. The temperature limits and current-carrying capacities for the communication wires specified in HD 384.5.523 shall not be exceeded.

© 2019 Signify Holding. All rights reserved. Specifications are subject to change without notice. No representation or warranty as to the accuracy or completeness of the information included herein is given and any liability for any action in reliance thereon is disclaimed. Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. All other trademarks are owned by Signify Holding or their respective owners.



www.lighting.philips.com/dynalite

AZZ 473 0718 R13